



Cumulus Linux Conversion Guides

Cumulus Networks

May 24, 2016

Where did things move?

Cisco

```
vlan 100,200

interface ethernet 1/1
  switchport mode access
  switchport access vlan 100

interface ethernet 1/2
  switchport mode access
  switchport access vlan 200
```

Juniper

```
interfaces {
  ge-0/1/1 {
    unit 0 {
      family bridge {
        interface-mode access;
        vlan-id 100;
      }
    }
  }
  ge-0/1/2 {
    unit 0 {
      family bridge {
        interface-mode access;
        vlan-id 200;
      }
    }
  }
}
```

Cumulus Linux

/etc/network/interfaces:

```
auto bridge
iface bridge
  bridge-vlan-aware yes
  bridge-ports swp1 swp2
  bridge-vids 100 200

auto swp1
iface swp1
  bridge-access 100

auto swp2
iface swp2
  bridge-access 200
```

Cumulus Linux

```
cumulus@switch:~$ sudo vi /etc/network/interfaces
auto swp1
iface swp1

auto bridge
iface bridge
    bridge-ports swp1
```

Cisco

```
switch# configure terminal
switch(config)# interface ethernet 1/1
switch(config-if)# switchport
```

Cumulus Linux

```
cumulus@switch:~$ sudo vi /etc/network/interfaces
auto swp1
iface swp1
    address [ipv4-address/subnet-mask]
    address [ipv6-address/subnet-mask]
```

Cisco


```
switch# configure terminal
switch(config)# interface ethernet 1/1
switch(config-if)# no switchport
switch(config-if)# ip address [ipv4-address/subnet-mask]
switch(config-if)# ipv6 address [ipv6-address/subnet-mask]
```

Cumulus Linux

```
cumulus@switch:~$ sudo vi /etc/network/interfaces
auto swp1
iface swp1
    link-speed [speed]
    link-duplex [full|half]
    mtu [1500 - 9216]
    link-autoneg [on|off]
```

Cisco

```
switch# configure terminal
switch(config)# interface ethernet 1/1
switch(config-if)# speed [speed]
switch(config-if)# duplex [full|half]
switch(config-if)# mtu [1500 - 9216]
switch(config-if)# [no] negotiate auto
```



Cumulus Linux


/etc/network/interfaces:

```
auto bridge
iface bridge
bridge-vlan-aware yes
bridge-ports glob swp1-2
bridge-vids 100 200
```

Cisco

```
vlan 100,200

interface ethernet 1/1
switchport mode trunk
interface ethernet 1/2
switchport mode trunk
```



Cumulus Linux

/etc/network/interfaces:

```
auto bridge
iface bridge
    bridge-vlan-aware yes
    bridge-ports glob swp1-2
    bridge-vids 100 200


auto swp1
iface swp1
    bridge-vids 200
```

Cisco

```
vlan 100,200

interface ethernet 1/1
    switchport mode trunk
    switchport trunk allowed vlan 200

interface ethernet 1/2
    switchport mode trunk
```



Cumulus Linux

/etc/network/interfaces:

```
auto bridge
iface bridge
    bridge-vlan-aware yes
    bridge-ports glob swp1-2
    bridge-vids 100 200

auto swp1
iface swp1
    bridge-access 100

auto swp2
iface swp2
    bridge-access 200
```


Cisco

```
vlan 100,200

interface ethernet 1/1
    switchport mode access
    switchport access vlan 100

interface ethernet 1/2
    switchport mode access
    switchport access vlan 200
```


Changing the Native (Untagged) VLAN for a Single Trunk



Cumulus Linux

/etc/network/interfaces:

```
auto bridge
iface bridge
    bridge-vlan-aware yes
    bridge-ports glob swp1-2
    bridge-vids 1-200

auto swp1
iface swp1
    bridge-pvid 100

auto swp2
iface swp2
    bridge-pvid 200
```


Cisco

```
vlan 1-200

interface ethernet 1/1-2
    switchport mode trunk
    switchport trunk allowed vlan 1-200

interface ethernet 1/1
    switchport trunk native vlan 100

interface ethernet 1/2
    switchport trunk native vlan 200
```



Cumulus Linux

/etc/network/interfaces:


```
auto bond1
iface bond1
    bond-slaves glob swp19-20
    bond-miimon 100
    bond-min-links 1
    bond-mode 802.3ad
    bond-xmit-hash-policy layer3+4
    bond-lacp-rate 1

auto vlan10
iface vlan10
    bridge-ports bond1.10
    address 10.10.10.11/24
    bridge-stp on
```

Cisco

Cisco WS-C3560X-24 12.2(55)SE5

```
vlan 10
!
interface GigabitEthernet0/19
    switchport trunk encapsulation dot1q
    switchport mode trunk
    channel-group 1 mode active
interface GigabitEthernet0/20
    switchport trunk encapsulation dot1q
    switchport mode trunk
    channel-group 1 mode active
interface Port-channel1
    switchport trunk encapsulation dot1q
    switchport mode trunk
interface Vlan10
    ip address 10.10.10.10 255.255.255.0
```



Cumulus Linux

/etc/network/interfaces:


```
auto bond2
iface bond2
    bond-slaves glob swp37-38
    bond-miimon 100
    bond-min-links 1
    bond-mode 802.3ad
    bond-xmit-hash-policy layer3+4
    bond-lacp-rate 1

auto vlan12
iface vlan12
    bridge-ports bond2.12
    address 12.12.12.11/24
    bridge-stp on
```

Arista

Arista DCS-7148S-R 4.13.5F

```
interface Ethernet37
    switchport mode trunk
    channel-group 2 mode active
interface Ethernet38
    switchport mode trunk
    channel-group 2 mode active
interface Port-Channel2
    switchport trunk allowed vlan 12
    switchport mode trunk
interface Vlan12
    ip address 12.12.12.12/24
```



Cumulus Linux

/etc/network/interfaces:

```
auto bond3
iface bond3
    bond-slaves glob swp39-40
    bond-miimon 100
    bond-min-links 1
    bond-mode 802.3ad
    bond-xmit-hash-policy layer3+4
    bond-lacp-rate 1

auto vlan14
iface vlan14
    bridge-ports bond3.14
    address 14.14.14.11/24
    bridge-stp on
```

Cisco

Cisco Nexus3064 5.0(3)U2(2c)

```
feature interface-vlan
feature lacp
vlan 14

interface Ethernet1/39
    switchport mode trunk
    channel-group 3 mode active
interface Ethernet1/40
    switchport mode trunk
    channel-group 3 mode active
interface port-channel3
    switchport mode trunk

interface Vlan14
    no shutdown
    ip address 14.14.14.14/24
```

Immediately bring an interface configured as an access or trunk port to the forwarding state.

Cumulus Linux

```
auto swp1
iface swp1
mstpctl-portadmedge yes
```

Cisco

```
interface Gigabit0/0
spanning-tree portfast
```

Enabling/disabling the BPDU guard configuration.

Cumulus Linux

```
auto swp1
iface swp1
    mstpctl-bpduguard yes
```

Cisco

```
!
spanning-tree portfast bpduguard default
!
interface Gigabit0/0
    spanning-tree portfast
```

Enables BPDU filter on a switch port, which filters BPDUs in both directions.

Cumulus Linux

```
auto swp1
iface swp1
    mstpctl-portbpdufilter yes
```

Cisco

```
!
spanning-tree portfast bpdufilter default
!
interface Gigabit0/0
    spanning-tree portfast
```

Configure the port priority for an interface. The default for both operating systems is 128.

Cumulus Linux

```
auto swp1
iface swp1
    mstpctl-treeportprio 128
```

Cisco

```
interface Gigabit0/0
    spanning-tree port-priority 128
```


Configure the switch's priority for a bridge/VLAN. The default for both operating systems is 32768.


Cumulus Linux

```
auto vlan1
iface vlan1
    mstpctl-treeprio 32768
    bridge-ports swp1
```

Cisco

```
spanning-tree vlan 1 priority 32768
```

<https://support.cumulusnetworks.com/hc/en-us/articles/206908397>



Spanning Tree
Industry-standard Loop Prevention for L2

(Example permit http port 80 traffic to 10.10.10.0/24 subnet)

iptables/netfilter (including Cumulus Linux)

```
iptables -A {FORWARD | INPUT | OUTPUT} -j {ACCEPT | DROP | POLICE | SPAN | ERSPAN} | -p <protocol>  
-s <source> --sport [<ports>] -d <destination> --dport [<ports>] [<options>]
```

```
iptables -A FORWARD -j ACCEPT -p tcp -s 10.10.10.0/24 -d 3.3.3.3/24 --dport 80
```

IOS Standard Syntax

```
access-list <number> {permit | deny} <protocol> <source> [<ports>] <destination> [<ports>] [<options>]
```

```
access-list 10 permit tcp 10.10.10.0/24 3.3.3.3/24 eq www
```

IOS Extended Syntax (including NX-OS)

```
ip access-list extended {<number> | <name>}  
  [<sequence>] {permit | deny} <protocol> <source> [<ports>] <destination> [<ports>] [<options>]
```

```
ip access-list extended allow_http  
  10 permit tcp 10.10.10.0/24 3.3.3.3/24 eq www
```

Cumulus Linux

```
iptables -A FORWARD -j DROP -i swp1 -p icmp --icmp-type echo-request
```

Cisco

```
ip access-list extended block_icmp
  deny icmp any any echo

interface g0/0
  ip access-group block_icmp in
```

Cumulus Linux

```
iptables -A INPUT -j DROP -p tcp -s 5.5.5.0/24 --dport 22
```

Cisco

```
ip access-list extended block_ssh  
  deny tcp 5.5.5.0 0.0.0.255 192.50.50.0 0.0.0.255 eq 22  
interface g0/0  
  ip access-group block_ssh in
```

Cumulus Linux

```
iptables -A FORWARD -j ACCEPT -p udp -s 192.168.1.0/24 --dport 123
```

Cisco

```
ip access-list extended allow_ntp  
  permit udp 192.168.1.0 0.0.0.255 any eq ntp  
interface g0/0  
  ip access-group allow_ntp in
```

Cumulus Linux

```
-A FORWARD --in-interface swp1 -j POLICE --set-mode KB --set-rate 125000 --set-burst 2000
```

Output

```
cumulus@leaf1$ sudo cl-acltool -L ip | grep swp1
pkts bytes target prot opt in out source destination
0 0 POLICE all -- swp1 any anywhere anywhere POLICE mode:KB rate:125000 burst:2000
```

Cisco

```
policy-map sean
class class-default
  police cir 1000000000 interface
TenGigabitEthernet1/13
  service-policy input sean
```

Cumulus Linux

```
-A FORWARD --in-interface swp2 -m dscp --dscp 10 -j POLICE --set-mode KB --set-rate 31250 --set-burst 2000
```

Output

```
cumulus@leaf1$ sudo cl-acltool -L ip | grep swp2
pkts bytes target prot opt in out source destination
0 0 POLICE all -- swp2 any anywhere anywhere DSCP match 0x0a POLICE mode:KB rate:31250 burst:2000
```

Cisco

```
class-map match-all dscp10
  match dscp af11
!
policy-map sean2
  class dscp10
    police cir 250000000
!
interface TenGigabitEthernet1/14
  service-policy input sean2
```


Cumulus Linux

```
-A FORWARD --in-interface swp3 -j POLICE --set-mode KB --set-rate 12500 --set-burst 2000 -s 3.3.3.0/24
```

Output

```
cumulus@leaf1$ sudo c1-acltool -L ip | grep swp3
pkts bytes target prot opt in out source destination
0 0 POLICE all -- swp3 any 3.3.3.0/24 anywhere POLICE mode:KB rate:12500 burst:2000
```

Cisco

```
access-list 100 permit ip 3.3.3.0 0.0.0.255 any
!
class-map match-all heller
  match access-group 100
!
policy-map heller
  class heller
    police cir 100000000
!
interface TenGigabitEthernet1/15
  service-policy input heller
```

Cumulus Linux

```
cumulus@switch:~$ sudo tzconfg  
cumulus@switch:~$ sudo hwclock
```

Cisco

```
switch# configure terminal  
switch(config)# clock timezone PST -8 0  
switch(config)# exit  
switch# show clock  
switch# copy running-config startup-config
```

Cumulus Linux

```
cumulus@switch:~$ sudo vi /etc/ntp.conf  
cumulus@switch:~$ ntpd -q
```

Cisco

Set NTP (e.g. to VDC 1)

```
switch# clock protocol ntp vdc 1
```

Cumulus Linux

```
cumulus@switch:~$ ifquery eth0
```

Cisco

```
switch# show interface mgmt 0
```

Cumulus Linux

```
cumulus@switch:~$ sudo vi /etc/default/isc-dhcp-relay  
SERVERS="192.168.123.4"  
INTERFACES="bridge swp4 swp5"  
  
cumulus@switch:~$ sudo /etc/init.d/isc-dhcp-relay restart
```

Cisco

```
switch# configure terminal  
switch(config)# ip dhcp relay  
switch# configure terminal  
switch(config)# interface ethernet 1/1  
switch(config-if)# ip dhcp relay address 192.168.123.4
```

Cumulus Linux

Cisco

Show command history

```
cumulus@switch:~$ history
```

```
switch# show cli history
```

Send message to all logged on users

```
cumulus@switch:~$ echo message | sudo wall
```

```
switch# send message
```

Send message to specific user

```
cumulus@switch:~$ sudo write user-id
```

```
switch# show users  
switch# send session line message
```

Cumulus Linux

Show SPROM information

```
cumulus@switch:~$ decode-syseeprom
```

Cisco

```
switch# show sprom
```

Show hardware states (temperature, fan, power)

```
cumulus@switch:~$ sudo smonctl
```

```
switch# show environment
```

```
cumulus@switch:~$ sudo sensors
```

Show memory allocation

```
cumulus@switch:~$ vmstat
```

```
switch# show processes memory
```

Show real-time memory usage

```
cumulus@switch:~$ vmstat 1
```

Alternative command

```
cumulus@switch:~$ free
```

Cumulus Linux

Show CPU processes and utilization

```
cumulus@switch:~$ ps aux
```

```
cumulus@switch:~$ top
```

Cisco

```
switch# show processes
```

```
switch# show processes cpu
```

Show hardware information

```
cumulus@switch:~$ dmidecode
```

```
cumulus@switch:~$ netshow system
```

```
switch# show inventory
```

Show high level port state

```
cumulus@switch:~$ netshow interface
```

```
switch# show ip int br
```


Cumulus Linux

Cisco

Show interface neighbors

```
cumulus@switch:~$ lldpctl
```

```
switch# show lldp neighbors
```

```
cumulus@switch:~$ netshow lldp
```

Show interface connector information

```
cumulus@switch:~$ sudo ethtool -m swp1
```

```
switch# show interface ethernet 1/1 transceiver
```

Reboot switch

```
cumulus@switch:~$ sudo reboot
```

```
switch# reload
```

Cumulus Linux

```
root@leaf01:~# arp -n
```

Address	Hwtype	Hwaddress	Flags	Mask	Iface
10.2.0.254	ether	44:38:39:00:00:29	C		eth0
169.254.1.2	ether	44:38:39:00:00:30	C		peerlink.4094
169.254.0.1	ether	44:38:39:00:00:08	CM		swp49
169.254.0.1	ether	44:38:39:00:00:14	CM		swp50

Cisco

```
switch# show ip arp
```

```
IP ARP Table for context default
```

```
Total number of entries: 1
```

Address	Age	MAC Address	Interface
90.10.10.2	00:03:11	000d.ece7.df7c	Vlan900

Cumulus Linux

```
cumulus@switch:~$ sudo vi /etc/snmp/snmpd.conf  
cumulus@switch:~$ sudo vi /etc/snmp/snmptrapd.conf
```

Cisco

```
switch# configure terminal  
switch(config)# snmp-server host ip-address traps version 2c public
```

Detailed Info

<https://docs.cumulusnetworks.com/display/DOCS/Monitoring+System+Hardware>

Bringing the Linux Revolution to Networking



Thank You!

© 2016 Cumulus Networks. CUMULUS, the Cumulus Logo, CUMULUS NETWORKS, and the Rocket Turtle Logo (the “Marks”) are trademarks and service marks of Cumulus Networks, Inc. in the U.S. and other countries. You are not permitted to use the Marks without the prior written consent of Cumulus Networks. The registered trademark Linux® is used pursuant to a sublicense from LMI, the exclusive licensee of Linus Torvalds, owner of the mark on a world-wide basis. All other marks are used under fair use or license from their respective owners.